

HIOKI

MODULES FOR MEMORY HiCORDERS

Instruction Manual

May 2026 Revised edition 12
8986A980 12

EN

8966	ANALOG UNIT
8967	TEMP UNIT
8968	HIGH RESOLUTION UNIT
U8969	STRAIN UNIT
8970	FREQ UNIT
8971	CURRENT UNIT
8972	DC/RMS UNIT
8973	LOGIC UNIT
U8974	HIGH VOLTAGE UNIT
U8975	4CH ANALOG UNIT
U8976	HIGH SPEED ANALOG UNIT
U8977	3CH CURRENT UNIT
U8978	4CH ANALOG UNIT
U8979	CHARGE UNIT
MR8990	DIGITAL VOLTMETER UNIT
U8991	DIGITAL VOLTMETER UNIT
U8993	ARBITRARY WAVEFORM GENERATOR UNIT
MR8790	WAVEFORM GENERATOR UNIT
MR8791	PULSE GENERATOR UNIT
U8794	VIR GENERATOR UNIT

HIOKI

HIOKI E.E. CORPORATION

See and published by HIOKI E.E. CORPORATION

- Contents subject to change without notice
- This document contains copyright content
- It is prohibited to copy, reproduce or in any way the content of this document without permission
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies

Europe only

- EU declaration of conformity can be downloaded from our website
- Contact in Europe: HIOKI EUROPE GmbH

Information on download site


For details on the product application, the update file for the instrument, and the instruction manual, please check HioKI's website

If you wish to update the Memory HiCorder to use the U8793, MR8790, or MR8791, visit our website to download a corresponding file

Thank you for purchasing the module designed for use with HioKI's Memory HiCorder. For more detailed information about operating precautions, module installation, and specifications, please see the instruction manual that came with the Memory HiCorder

Installing the Modules

- 1 Remove the connection cords from all modules.
- 2 Turn off the instrument, and disconnect the power cord.
- 3 Remove the two fixing screws with a Phillips screwdriver (No. 2).
- 4 Pinch the two knobs and pull out the module.
- 5 Orient the module and insert it all the way into the instrument.
- 6 Tighten the two module mounting screws with the Phillips screwdriver.



Warranty Certificate

HIOKI

Model	Serial number	Warranty period
Customer name		Please fill in from date of purchase
Notes: Please retain this warranty certificate. HioKI will accept no liability for damage to the product or its performance caused by the use of the product for purposes other than those specified in the instruction manual. This warranty certificate is valid only for the product as supplied by HioKI. It does not cover damage caused by the use of the product for purposes other than those specified in the instruction manual. For details on the product application, the update file for the instrument, and the instruction manual, please check HioKI's website.		

Run-off to the

1. The product is not covered by this warranty if the user has modified the product or its performance.
2. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.
3. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.
4. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.
5. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.
6. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.
7. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.
8. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.
9. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.
10. The product is not covered by this warranty if the user has used the product for purposes other than those specified in the instruction manual.

HIOKI E.E. CORPORATION

Memory HiCorders that support the modules

✓ supported not supported

Memory HiCorder	MR8848	MR8827	MR8000 MR6000-01	MR8740T (MR8740-50)	8847*1 MR8847-01*1 MR8847-02*1 MR8847-03*1	MR8847A*1 (MR8847-51*1, MR8847-52*1, MR8847-53*1)	MR8740*1	MR8741*1
8966	✓	✓	✓	✓	✓	✓	✓	✓
8967	✓	✓	✓	✓	✓	✓	✓	✓
8968	✓	✓	✓	✓	✓	✓	✓	✓
U8969	✓	✓	✓	✓	✓	✓	✓	✓
8970	✓	✓	✓	✓	✓	✓	✓	✓
8971	✓	✓	✓	✓	✓	✓	✓	✓
8972	✓	✓	✓	✓	✓	✓	✓	✓
8973	✓	✓	✓	✓	✓	✓	✓	✓
U8974	✓	(Ver 1.10 or later)	✓	✓	(Ver 3.2.0 or later)	✓	(Ver 3.2.0 or later)	(Ver 2.2.0 or later)
U8975	✓		✓	✓		(Ver 2.0.0 or later)		
U8976			✓					
U8977	✓		(Ver 2.1.0 or later)	(Ver 2.0.0 or later)		(Ver 2.0.0 or later)		
U8978	✓		(Ver 2.1.0 or later)	(Ver 2.0.0 or later)		(Ver 2.0.0 or later)		
U8979	✓	(Ver 1.2.0 or later)	(Ver 2.1.0 or later)	(Ver 2.0.0 or later)		(Ver 1.1.0 or later)	(Ver 3.3.0 or later)	(Ver 2.3.0 or later)
MR8990	✓	✓	✓	✓		✓	✓	✓
U8991				✓				
U8793	✓	(Ver 1.1.0 or later)	(Ver 3.5.0 or later)	(Ver 3.0.0 or later)		✓	(Ver 3.2.0 or later)	(Ver 2.2.0 or later)
MR8790	✓	(Ver 1.1.0 or later)	(Ver 4.0.0 or later)	(Ver 3.0.0 or later)		✓	(Ver 3.2.0 or later)	(Ver 2.2.0 or later)
MR8791	✓	(Ver 1.1.0 or later)	(Ver 4.0.0 or later)	(Ver 3.0.0 or later)		✓	(Ver 3.2.0 or later)	(Ver 2.2.0 or later)
U8794				✓				

*1 Discontinued products

Symbols for various standards



Indicates that the product complies with Korean regulations
Declarer HIOKI KOREA CO., LTD

HIOKI 8986A980 12