

engage HUB SOLO

QUICK START GUIDE
GUÍA RÁPIDA DE INICIO



REDUCE

MONITOR

SAVE





efergy

efergy

CHECK YOUR EXISTING EFERGY MONITOR

The engage hub solo needs to link up with the efergy transmitter and sensor(s) you installed previously for your efergy monitor. Check the monitor to make sure they are working correctly.



Classic Transmitter



Breaker Transmitter




CT



IR/OPT



TPM AC/AC



1


CONNECTING THE ENGAGE HUB

1. Plug the engage hub into a mains power source using the supplied AC adaptor, and into a spare port on a router with internet access using the LAN cable provided.

2. There are 3 lights on the top of the hub. First, the red light will light continuously, showing that the hub is powered on. The yellow light (centre) will come on next, indicating that the hub is looking for a transmitter within range. A green light states that a working internet connection has been connected to the hub.

3. Within a minute or two you should see both the yellow light and green light come on and stay on solid for a few seconds and then go out. The lights may or may not illuminate at the same time. Once you see the yellow and green lights come on for a few seconds and then go out, you are ready to register your engage hub.

Note: If your router does not recognize your new hub, the router may need to be reset. Simply do this by pushing the reset button on the router itself (sometimes this requires the use of a paper clip).



2

SETTING UP THE ONLINE SERVICE

Visit <http://engage.efergy.com>, sign up and follow our step by step setup process on-screen. It may be more comfortable for you to carry out this process on a laptop near where the transmitter is installed or get someone to assist you during the pairing process.




LINKING THE TRANSMITTER

When prompted by the on-screen instructions, complete installation by pressing Link button on the website and on your transmitter. This must be done within 30 seconds of each other. You may press the link button on the transmitter several times during this time. Do not press and hold this button, simply push and release it each time for period.



3


WHAT'S IN THE BOX



1x engage hub



1x Ethernet Cable



1 x Changeable adaptor

TECHNICAL INFORMATION

Transmission Frequency/
Transmission time /
Transmission range /
Engage hub power /

433.5MHz
10/15/20s
40 - 70m
AC/DC Adaptor



4

CUSTOMER SUPPORT



If you have any problems at any point during registration please check the FAQs within the Help section at:

Alternatively, if you have any questions about using your installation guide or want further information on saving energy, you can contact Roger or visit our website.



CE RoHS



FC

